

**Models CG70ABDL
& CG70BDL**

Corrosion Gauge

Operating Instructions



This product meets the Electromagnetic Compatibility Directive.

The product is Class A, Group 1 ISM equipment according to CISPR 11

Group 1 ISM product: A product in which there is intentionally generated and/or used conductively coupled radio-frequency energy which is necessary for the internal functioning of the equipment itself.

Class A product are suitable for use in all establishments other than domestic and those directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

Note: In the close presence of some radio transmitters, erroneous readings may be given. If this occurs tests should be repeated at another location.

These operating instructions are available for download on our website www.elcometerNDT.com.

The following trademarks are registered trademarks of Elcometer Limited, Edge Lane, Manchester, M43 6BU. United Kingdom:



Material Safety Data Sheets for the ultrasonic couplant supplied with the CG70ABDL & CG70BDL and available as an accessory, are available to download via our website:

Elcometer Ultrasonic Couplant Material Safety Data Sheet :

www.elcometer.com/images/MSDS/elcometer_ultrasonic_couplant.pdf

www.elcometer.com/images/MSDS/elcometer_ultrasonic_couplant_blue.pdf

Elcometer Ultrasonic Couplant (High Temperature) Material Safety Data Sheet :

www.elcometer.com/images/MSDS/elcometer_ultrasonic_couplant_hi_temp.pdf

All other trademarks acknowledged. © Elcometer Limited 2011/2014. All rights reserved. No part of this document may be reproduced, transmitted, transcribed, stored (in a retrieval system or otherwise) or translated into any language, in any form or by any means (electronic, mechanical, magnetic, optical, manual or otherwise) without the prior written permission of Elcometer Limited.

Contents

| | | |
|----|---|----|
| 1 | About your Gauge | 3 |
| 2 | The Keypad | 4 |
| 3 | Getting Started | 5 |
| 4 | The Menu | 5 |
| 5 | The Measurement Screen | 6 |
| 6 | Measurement - Modes | 10 |
| 7 | Setting up the Gauge | 11 |
| 8 | Taking Readings | 13 |
| 9 | Gates (CG70ABDL only) | 14 |
| 10 | Thru-Paint™ measurement technique | 14 |
| 11 | Measurement - Options | 14 |
| 12 | Flaw Mode (CG70ABDL only) | 16 |
| 13 | Measurement - Recording your Readings | 17 |
| 14 | Gauge Setups | 19 |
| 15 | Data Transfer Software | 20 |
| 16 | Storage | 21 |
| 17 | Maintenance | 21 |
| 18 | Technical Specification | 22 |
| 19 | Warranty | 22 |
| 20 | Spares & Accessories | 23 |
| 21 | Condition and preparation of surfaces | 24 |
| 22 | Application notes | 24 |
| 23 | Sound Velocities of Common Materials | 25 |
| 24 | The Menu Commands | 25 |

Thank you for purchasing this Elcometer NDT product. Welcome to Elcometer NDT. The CG70 range of Corrosion Gauges are a world beating product. With the purchase of this gauge you now have access to the worldwide service and support network of Elcometer. For more information visit our website at www.elcometerNDT.com.

1 ABOUT YOUR GAUGE


The CG70 series are corrosion gauges that measure with extreme versatility. They have the ability to measure material thickness as well as locating pits, flaws and defects in the material. Based on the same operating principles as SONAR and are capable of measuring the thickness of various materials with accuracy as high as $\pm 1\%$ or ± 0.01 millimetres ($\pm 0.005''$) whichever is the greater. The principal advantage of ultrasonic measurement over traditional methods is that ultrasonic measurements can be performed with access to only one side of the material being measured. Both models also include a data-logging (memory) facility which allows readings to be stored in batches before being downloaded to a computer.

Note : *Some functions are only applicable to certain models and these are highlighted throughout this Instruction Manual*

1.1 STANDARDS

Your gauge can be used in accordance with the following Standards and test methods; ASTM E 797, EN 14127 and EN 15317.

1.2 GAUGE OVERVIEW & WHAT THIS BOX CONTAINS



1. Transducer connection
2. Alarm LEDs
3. Battery compartment cover and zero block
4. Display
5. Keypad
6. RS232 Output Socket

CG70 series gauge, Bottle of couplant, Battery (3 x), Carrying case, Test Certificate, Operating instructions, CD with software to enable you to transfer your readings and settings to and from a PC, RS232 cable and USB to serial converter.

*Note: The box does **not** include a transducer; these must be ordered separately.*

1.3 FEATURES OF THE GAUGE

- Adjustable gain settings.
- Stores up to 64 custom setups for specific applications.
- High speed scan mode of up to 50 readings per second.
- Audible/visual alarm with high and low limit settings.
- RF and RECT A-Scan displays (CG70ABDL only).
- Time based B-Scan display.

- Measurement data storage formats: Alpha numeric grid.
Data can be downloaded to a computer for analysis and storage.

To maximise the benefits of your new Elcometer NDT gauge, please take some time to read these Operating Instructions. Do not hesitate to contact Elcometer NDT or your Elcometer NDT supplier if you have any questions.

1.4 PACKAGING

The gauge is packed inside its carrying case within a cardboard box. Please ensure that the packaging is disposed of in an environmentally sensitive manner. Consult your Local Environmental Authority for further guidance.

2 THE KEYPAD

| | |
|---|--|
|  | Activates the primary menu structure containing 7 (CG70BDL) & 9 (CG70ABDL) menu tab groups. These tab groups then contain sub menu items, or functions. |
|  | Clears a measurement from a log file cell location or set obstruct and back-space in an Alpha Edit Box. |
|  | Press to start taking measurements. Scroll forwards through the hot menu. |
|  | Press to confirm a change or selection. When in measurement mode, enables or disables the Hot Menu. If your gauge is displaying a grid log, this key toggles an advance to row number option. |
|  | In the MENU, MEAS, and EDIT functions this key acts as a back or escape function. If your gauge is displaying a grid the ESC key toggles the display options; RF, RECT (CG70ABDL only) B-SCAN or DIGITS (all models) |
|  | Navigation keys. |
|  | In menus this key activates list and edit boxes, displays and saves measurements to grid files locations. |
|  | Press to select a measurement mode. The measurement modes available depend on which transducer is being used. See Section 6 “Measurement - Modes” on page 10. |
|  | Switches the gauge ON or OFF. |

3 GETTING STARTED

3.1 FITTING BATTERIES

Your gauge may be used with dry cell or rechargeable batteries. 3 x LR6 (AA) alkaline batteries are supplied with this gauge.

When the battery voltage is low the entire display will start to flash. When this occurs the batteries should be replaced.

To fit or replace batteries:

1. Unscrew battery compartment cover.
2. Referring to battery polarity instructions on rear of gauge, insert batteries.
3. Replace battery compartment cover.

Note: Remove the batteries from the gauge if it is to remain unused for a long period of time. This will prevent damage to the gauge in the event of malfunction of the batteries.

3.2 FITTING THE TRANSDUCER

The transducer transmits and receives ultrasonic sound waves that the gauge uses to calculate the thickness of the material being measured.

The transducer connects to the gauge via the attached cable, and two coaxial connectors. When using transducers manufactured by Elcometer, the orientation of the dual coaxial connectors is not critical; either plug may be fitted to either socket.



Further information on transducers can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com.

3.3 SWITCHING ON/OFF

To switch on or off, press the on/off key .


The gauge will switch off automatically after 5 minutes of inactivity.

4 THE MENUS




Your gauge has two menu systems:

- Full menu - displays all the functions and settings of the gauge (see also page 25).
- Hot menu - displays a sub-set of functions and settings related to taking measurements.

4.1 FULL MENU

| | | | |
|--|--|---|---|
| Press MENU once to access the menus... | then press MENU to scroll to the right along the sub menu bar and ESC to scroll left to the sub menu you want. | UP and DOWN scroll to the desired function | LEFT and RIGHT adjust the selected function |
| |  |  |  |

4.2 HOT KEY MENU

| | | | |
|--|---|---|--|
| <p>Press MEAS once to access the measurement screen. The hot menu functions are displayed at the bottom of the reading screen.</p> | <p>Press MEAS to scroll right along the hot menu functions and ESC to scroll left</p> | <p>Use UP, DOWN, LEFT and RIGHT to adjust the value of the function.</p> | <p>Alternatively, adjust values by pressing ENTER then use UP, DOWN, LEFT and RIGHT to scroll and adjust values. Press OK when finished.</p> |
|  |  |  |  |

4.3 OVERVIEW

Throughout these instructions menu locations will be described using a simple system to guide the user. Locations or menu items will be described in the order that they must be navigated to separated by a "/".

For example, to reach the option "Zero Transducer" MENU/PROBE/ZERO TRANSDUCER would be written. After adjusting the desired function press MEAS to return to the measurement screen.

4.4 SELECTING MENU LANGUAGE





The menus can be displayed in English, Spanish, and German.

1. Select MENU/SETUP/LANGUAGE and adjust.

5 THE MEASUREMENT SCREEN

Your gauge has up to four types of measurement screen:

- A-Scan Waveform, RF (CG70ABDL only)
- A-Scan Waveform, RECT (CG70ABDL only)
- B-Scan
- Digits


| | | | |
|---|---|--|--|
| <p>A-SCAN RF</p>  | <p>A-SCAN RECT</p>  | <p>B-SCAN</p>  | <p>DIGITS</p>  |
|---|---|--|--|

To see the measurement screen, press MEAS.

To select which measurement screen to use, press MENU/DISP/VIEW and then select RF, RECT, B-SCAN or DIGITS.

5.1 ITEMS COMMON TO ALL MEASUREMENT SCREENS

A number of items are common to all the measurement screens:




| | | |
|---|--|--|
| A | Battery Icon | Remaining battery life. |
| B | Repeatability/Stability Indicator | This indicator is used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, your gauge is reliably measuring the value. |
| C | Material Thickness Value/ Material Velocity Value | The thickness or sound velocity of the material under the transducer (type depends upon measurement view). |
| D | Units | The current measurement units (Metric/English). |
| E | Measurement View Area | RF, RECT, B-SCAN or DIGITS view area. |
| F | Measurement Labels Bar | Displays the viewable range and are based on the values of DELAY/B-START and WIDTH/B-DEPTH. |
| G | Hot Menu (CG70ABDL only) | The hot menu contains a selection of the most commonly used options, allowing you to conveniently adjust these to your needs while the graphical display is active. |

5.2 RF A-SCAN MEASUREMENT SCREEN (CG70ABDL only)

The RF view shows the full sound wave as received by the gauge. The vertical axis indicates the amplitude of the received wave and the horizontal position indicates the time it is received, which is converted into thickness units using the material velocity.

The point on the scan that is being used to calculate the digital thickness reading is displayed as the vertical dashed line (see section 9 on gates). The RF screen is used for gauge setup prior to inspection.



5.3 RECT A-SCAN MEASUREMENT SCREEN (CG70ABDL only)


The rectified view shows only half of the waveform, either the positive or negative half depending on the POLARITY selected. The RECT display is the preferred view for flaw and pit inspections.

5.4 B-SCAN MEASUREMENT SCREEN

The time-based B-Scan display provides a cross sectional view of the material being tested. In this example, the top, or accessible side of the material is represented as 0.00", and the bottom, or blind surface at .500".


This mode is used when you need to inspect the profile of the blind surface. It can also be a useful view when scanning for pits and flaws. The B-Scan display is equipped with a scan bar representing the overall thickness. The scan bar gives the user a visual indication when a flaw or defect passed over during the scan process.

If you are scanning a pipe, for instance, and pass over a pit during the process, the scan bar will quickly deflect and alarm you to go back and search for the defect.



5.5 DIGITS MEASUREMENT SCREEN

The digits display shows the thickness as a value using a large font size. This view is used typically when the gauge is being used as a basic thickness gauge. The digits display includes the same scan bar as the B-Scan display.



5.6 CHANGING THE VIEWABLE RANGE

In RF view, RECT view and B-SCAN view, if the waveform around the detection point is not visible on the display, use one of the following methods to adjust the viewable range of the display:

- When in RF view or RECT view, change the values of the DELAY and WIDTH functions until the measurement falls inside the viewable range of the display - see instructions below.
- When in B-SCAN view, change the values of the B-START and B-DEPTH functions until the measurement falls inside the viewable range of the display. B-START is the equivalent of DELAY and B-DEPTH is the equivalent of WIDTH and the instructions for changing these values is identical to those for DELAY and WIDTH - see instructions below.

- Use the Auto Find function - see 'Auto Find (CG70ABDL only)' on page 14.

Note: Even if the waveform is outside of the viewable range of the display, a measurement can be taken and viewed using the DIGITS view.

5.6.1 DELAY AND WIDTH

The DELAY is the thickness value from which the A-Scan display starts on the left of the screen. The WIDTH is used to adjust the value at the right side of the screen. Using these two parameters allows the user to zoom in to a specific measurement range and increase the level of detail on the display. For example, if a wall thickness was nominally 25mm and an operator was assessing for corrosion on this wall they might set the DELAY to 10mm and the WIDTH to 20mm to fit as much relevant information on the display as possible.

B-START and B-DEPTH are analogous to DELAY and WIDTH or a B-SCAN display respectively. DELAY and WIDTH or B-START and B-DEPTH may be adjusted in the hot menu or in the DISP section of the main menu.

5.6.2 Adjusting DELAY and WIDTH (or B-START and B-DEPTH)

The quickest way to adjust DELAY and WIDTH is directly from the hot menu. Alternatively, adjust the values using the menus:

1. Select MENU/DISP/DELAY or WIDTH and adjust using LEFT and RIGHT or press ENTER to use the DIGITS EDIT BOX.
2. Press OK to set the value.
3. Press MEAS to return to the measurement.

5.7 GAIN

The gain (the amplitude of the transmitted pulse) can be adjusted to suit a variety of applications. To obtain valid readings the gain must be set to the correct level to give reliable return echoes:

- Too much gain may result in erroneous measurements by detecting noise rather than the material back wall itself.
- Not enough gain may result in intermittent detection. It may also result in lack of detection on internal flaws, pits, or porosity.

The gain setting on your gauge can be compared to the volume control of a home stereo system. If you turn it up too much you cannot hear the music clearly. If it is turned down too much, you cannot hear it at all.

Note: When the echo-echo ThruPaint™ measurement mode is selected, the manual gain feature is disabled and greyed out in the menu items. In this mode, your gauge switches to an automatic gain mode (AGC) that optimises the gain setting automatically.

Your gauge has been optimised for a medium gain setting and for the majority of applications it can be used at this setting. Some applications however may require lower or higher gain settings:

- **Lower values** might be necessary for noisy or granular cast materials. If the reading becomes sporadic and will not settle down or resolve on a thickness value.
- **Higher values** may be necessary when trying to measure a material that is hard to penetrate (due to the material type, or the overall thickness of the material) and when locating fine pits or flaws. In these instances, increase the gain until the stability indicator reports a good measurement.

5.7.1 To Adjust the Gain Value

The quickest way to adjust GAIN is directly from the hot menu. Alternatively, adjust the value using the menus:

1. Select MENU/TUNE/GAIN and adjust using LEFT and RIGHT or press ENTER to use the DIGITS EDIT BOX.
2. Press OK to set the value.
3. Press MEAS to return to the measurement screen.

5.8 THRESHOLD (CG70ABDL only)

The threshold is the level of signal amplitude required to trigger a gate and activate the digital thickness reading. Increasing the threshold value decreases the sensitivity of the gauge as a more powerful signal is required to trigger the gate. For example on the A-scan display it may be clear that there is a flaw in the material but the thickness reading is not taking this into account; lowering the threshold has the effect of increasing the sensitivity of the gauge to a level that the flaw can be detected. More information on thresholds can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

5.8.1 To Adjust the Threshold Value

The threshold value may be adjusted from the hot menu when in the P-E GT or E-E measurement mode.

5.9 GATES (CG70ABDL only)

Your gauge is equipped with gates which control the time measurement process. Further information on gates can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

6 MEASUREMENT - MODES

To select the measurement mode, press MULTI MODE until the correct mode is displayed or select MENU/GATE/MEASURE MODE.

Note: The availability of the modes depends upon the type of transducer fitted to the gauge.

6.1 PULSE-ECHO MODE (P-E)

The standard measurement mode providing maximum sensitivity. This general purpose mode should be used for corrosion and flaw inspections and will measure the total thickness of a material.

6.2 PULSE ECHO WITH GATE MODE (P-E GT) (CG70ABDL only)

Pulse to echo measurement with an adjustable gate for problematic applications. see section 9 on gates.

6.3 ECHO-ECHO MODE (E-E), THRUPAINT™

This special mode allows the user to measure the material thickness of a substrate underneath a coating while ignoring the coating thickness by using two echoes from the material back wall. This mode is useful when the coating thickness makes up a sizeable proportion of a material, but has the impact of reducing sensitivity so should not be used in pit and flaw inspections.

6.4 FLAW MODE (CG70ABDL only)

The Model CG70ABDL includes a Flaw Mode function which provides basic prove-up flaw detection using an angle beam transducer. This mode enables inspectors to locate porosity, defects, inclusions and cracks in a variety of test materials. Further information on the Flaw Mode can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

For instructions on how to use the Flaw Mode see 'Flaw Mode (CG70ABDL only)' on page 16.

7 SETTING UP THE GAUGE

7.1 SELECTING THE TRANSDUCER TYPE MANUALLY

Follow these steps to select your transducer type.

1. Select MENU/PROBE/TYPE and press ENTER.
2. Scroll through the transducer list until the appropriate transducer is highlighted.
3. Press ENTER to select the transducer.
4. Perform a probe zero.

| | | | |
|---------------------------------|--------|-------|-----------|
| 1. | 3/16IN | - | 5.0MHZ |
| 2. | 3/16IN | - | 7.5MHZ |
| 3. | 3/16IN | - | 10.0MHZ |
| 4. | 1/4IN | - | 1.0MHZ |
| 5. | 1/4IN | - | 2.25MHZ |
| 6. | 1/4IN | - | 5.0MHZ |
| 7. | 1/4IN | - | 5.0MHZ HD |
| 8. | 1/4IN | - | 7.5MHZ |
| PROBE CAL DISP TUNE GATE | | | |
| ZERO TRANSDUCER | | | |
| PULSE | | SPIKE | |
| TYPE | | | 1 |
| FLAW MODE | | | OFF |

7.2 TRANSDUCER - ZEROING

Setting the zero point for the transducer is important in the same way it is important for a mechanical micrometer. Zeroing takes into account slight variations in the manufacturing process for maximum accuracy. If zeroing is not carried out correctly, the measurements taken by the gauge will be in error by some fixed value.

To perform a probe zero:

1. Press MEAS to display the measurement screen.
2. Remove all couplant from the face of the transducer and check that the wearface is clean and free of any debris.
3. Apply a drop of couplant on the transducer and place the transducer as shown in diagram.
Note: Disregard the value displayed; it is not important. What is important is accurately performing these steps to ensure reliability of the zero calculation.
4. Select MENU/PROBE/ZERO TRANSDUCER and press ENTER. The ZERO TRANSDUCER screen is displayed.
5. Press OK (or ESC to cancel).
When the manual probe zero is completed the measurement screen is displayed.
6. Remove the transducer from the probe zero disk.

Your gauge should now be zeroed.



7.3 CALIBRATING - FOR A MATERIAL

Sound travels through different materials at different speeds, and in order to measure these materials accurately the correct sound velocity must be programmed into the gauge. There are three methods of calibrating the gauge.

Known Material Calibration - The material to be measured is selected from a list in the gauge

Known Velocity Calibration - If the material sound velocity is known this may be entered manually into the gauge.

Known Thickness Calibration - A sample of the material to be inspected is measured using alternative means and then used to calibrate the gauge.

- **One Point** calibration is the simplest and most commonly used calibration procedure with best performance over large measurement ranges
- **Two Point** calibration uses two samples of different thicknesses, with enhanced accuracy over small ranges close to the sample thicknesses used

For the highest measurement accuracy use the known thickness calibration as this takes into account variation in material composition, temperature and a variety of other factors.

7.3.1 Known Material Calibration

If the material velocity is unknown, and a sample thickness cannot be taken from the material, you can choose a material type from a list stored in the gauge. For each material stored in the list there is a corresponding velocity value.

Note: These velocities will not always be an exact representation of the material being tested. Use these values only if a close approximation is acceptable.

1. Select MENU/CAL/MATERIAL and press ENTER.
2. Scroll through the material list until the appropriate material is highlighted
3. Press ENTER to select the material type followed by OK.
4. Press MEAS to return to the measurement screen.

7.3.2 Known Velocity Calibration

If the material velocity is known, you can enter the velocity value directly into the gauge. For a list of the sound velocities of common materials see 'Sound Velocities of Common Materials' on page 25

1. Select MENU/CAL/VELOCITY and press ENTER to display the DIGITS EDIT BOX.
2. Adjust to match the material velocity using the LEFT, RIGHT, UP and DOWN arrows then press OK.
3. Press MEAS to return to the measurement screen.

7.3.3 Known Thickness Calibration

If the sound velocity of a material is unknown, a sample with one or two known thicknesses can be used to determine the sound velocity.

Note: Although the gauge has a ThruPaint™/coating feature, known thickness calibration must be performed on material with the paint or coating removed.

One-point Calibration: The one point calibration option is most suited for linearity over large ranges. You should always calibrate on high side of the intended measurement range. For example, if the measurement range is 2.54 mm to 25.4 mm (.100" to 1.0"), you should calibrate on a known thickness sample close to 25.4 mm (1.0").

Note: Before you start this calibration procedure, perform a probe zero.

1. Apply a drop of couplant on the transducer and place the transducer in steady contact with the sample or the material being tested. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable.
2. Select MENU/CAL/ONE POINT and press ENTER to display the DIGITS EDIT BOX.
3. Adjust to match the material thickness using the LEFT, RIGHT, UP and DOWN arrows.
4. Press OK to calculate the velocity and return to the measurement screen, or ESC to cancel.

Note: Place the transducer back on the calibration point. The thickness reading should now match the known thickness but if outside tolerance, repeat the steps above.

Two-point Calibration: For improved accuracy over a smaller measurement range, conduct one-point calibration followed by a two-point calibration. For example, if the measurement range is 2.03 mm to 6.35 mm (.080" to 0.250"), perform a one point calibration on a known thickness sample close to 6.35 mm (.250"), followed by a two-point calibration close to 2.03 mm (.080").

Note: Before you start this calibration procedure, perform a probe zero.

Two - Point calibration

1. Conduct a one point calibration routine as described previously in this section. You should conduct this routine at the high end of the measurement range.
2. Repeat the routine with another sample at the low end of the measurement range, except this time enter the thickness into the TWO POINT area in the CAL menu.

Note: CHECK YOUR CALIBRATION. Place the transducer back on both calibration points. If the thickness is out of tolerance repeat the steps above.

8 TAKING READINGS

Disclaimer: Inherent in ultrasonic thickness measurement is the possibility that the instrument will use the second rather than the first echo from the back surface of the material being measured. This may result in a thickness reading that is TWICE what it should be.

Responsibility for proper use of the instrument and recognition of this phenomenon rests solely with the user of the instrument.

Other errors may occur from measuring coated materials where the coating is insufficiently bonded to the material surface. Irregular and inaccurate readings may result. Again, the user is responsible for proper use and interpretation of the measurements acquired.

8.1 BEFORE YOU START

- Prepare the surface.
- Ensure the correct transducer is selected and set in the gauge.
- Select the correct measurement mode - see 'Measurement - Modes' on page 10.
- Set the zero point of the transducer - see:
 - 'Transducer - Zeroing' on page 11 and
- Calibrate the gauge - see:
 - 'Calibrating - for a Material' on page 11 and
- Choose the measurement view (DIGITS, RF or RECT, or B-SCAN) - see 'The Measurement Screen' on page 6.

8.2 PROCEDURE

1. Apply couplant

For the gauge to work correctly there must be no air gap between the transducer and the surface of the material to be measured. This is achieved using a couplant.

Before the transducer is placed on the surface, put a small amount of couplant supplied with the gauge on the surface of the material. Typically a single drop is sufficient.

2. Place transducer onto the surface of the material to be measured

Press the transducer wearface into the couplant. Only moderate pressure is necessary to keep the transducer stationary and the wearface seated flat against the surface of the material.

3. Read display

If six or seven bars of the stability indicator are showing, the display will be reading the correct thickness of the material directly beneath the transducer.

If the stability indicator has fewer than five bars showing, or the numbers on the display seem erratic, check to make sure that there is an adequate film of couplant beneath the transducer, and that the transducer is seated flat against the material. If the condition persists, it may be necessary to:

- adjust the gain, or
- select a different transducer (size or frequency) for the material being measured.

The gauge will perform a number of measurements every second when the transducer is in contact with the surface of the material. The display is updated as each reading is taken.

4. Remove transducer from surface

The display will show the last measurement made.

Note: Occasionally, a small film of couplant will be drawn out between the transducer and the surface as the transducer is removed. When this happens, the gauge may perform a measurement through this couplant film. This phenomenon can be seen when one thickness value is observed while the transducer is in place, and another value is observed after the transducer is removed. If this happens, take the reading again using less couplant.

9 GATES (CG70ABDL only)

9.1 INTRODUCTION

The Model CG70ABDL is equipped with gates which control the time measurement process allowing you to measure a specific region on or between waveforms.

Further information on gates may be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

9.2 ADJUSTING THE GATES

In P-E GT mode one gate is available and may be adjusted from the hot menu. In E-E mode both gates may be adjusted from the hot menu or alternatively select MENU/GATE.

10 THRUPAINT™ MEASUREMENT TECHNIQUE

10.1 INTRODUCTION

Your gauge is equipped with a ThruPaint™ measurement mode that uses a multiple echo technique to allow measurement of the material thickness beneath a coating. This is useful for checking the material thickness of painted object.

ThruPaint™ capability is available in E-E mode, to activate ThruPaint™ operation select this measurement mode using the MULTI MODE key.

Special "High Damped" or Coating Thickness transducers are required for this mode to function.

Further information may be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

11 MEASUREMENT - OPTIONS

11.1 AUTO FIND (CG70ABDL only)

When using a scan type display, the DELAY and WIDTH (or B-START and B-DEPTH) must be set correctly for the waveform to be shown on the display. If these parameters are set up incorrectly nothing will be seen. The AUTO FIND function solves this problem by automatically adjusting these parameters so that the relevant part of the waveform is shown on the screen.

To use the AUTO FIND function place the transducer on the material to obtain a reading, select MENU/UTIL/AUTO FIND.

11.2 HIGH SPEED SCAN

Although your gauge excels at making single point measurements, it is sometimes desirable to examine a larger region, searching for the thinnest point. The gauge includes a feature, called Scan Mode, which allows it to do just that.

This mode increases the overall repetition rate to a maximum of 32 Hz with a high speed screen refresh rate of 25 times a second.

This feature enables the user to make scanned passes over an arbitrary length of the test material while still maintaining a reasonable representation of thickness over the scanned area or region. This feature can be used in conjunction with High and Low alarm limits features to keep track of both values dynamically.

To enable/disable the high speed Scan Mode:

1. Select MENU/UTIL/SCAN MODE.
2. Use the LEFT and RIGHT arrows to toggle the SCAN MODE on/off.
3. Press MEAS to return to the measurement screen, ready to begin taking readings.

11.3 ALARM MODE

Your gauge includes an Alarm Mode. Set the limits, and if a measurement falls outside of these limits your gauge will signal an alarm (a red light on the front panel of the instrument and/or an audible beep).

This feature may be used for a variety of applications to verify the material is within the manufacturer specifications.

There are two limit values, ALARM LOW and ALARM HIGH. You can choose to activate both or just one of these values depending on your requirements.

To enable/disable Alarm Mode:

1. Select MENU/UTIL/ALARM STATUS
2. Use the LEFT and RIGHT arrows to toggle the ALARM on/off/audible.
3. Press MEAS to return to the measurement screen, ready to begin taking readings.

To set the Alarm limits:

1. Select MENU/UTIL/ALARM LO LIMIT or ALARM HI LIMIT and press ENTER to display the DIGITS EDIT BOX.
2. Adjust to suit the measurement application using the LEFT, RIGHT, UP and DOWN arrows.
3. Press OK to set the alarm value and return to the menu screen, or ESC to cancel.
4. Press MEAS to return to the measurement screen.

11.4 POLARITY (CG70ABDL only)

The polarity that your gauge detects on can be set to either positive or negative to obtain the best detection results depending on the specific measurement conditions of your application. Polarity affects both the gate (above or below the x axis in the RF A-Scan) and the Rectified A-Scan display (whether the top or bottom half of the RF display is shown).

For further information refer to the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

To adjust POLARITY:

1. Set the measurement screen view to RF, MENU/DISP/VIEW.
2. Select MENU/TUNE/POLARITY.

11.5 PULSE WIDTH (CG70ABDL only)

Your gauge has an adjustable pulse width option. Pulse width refers to the duration of time the pulser is switched on. Pulse width determines the amount of energy transmitted into the material being tested.

There are three pulse width options:

Spike: The Spike option is used for high resolution and general applications and can be considered as the standard setting.

Thin: When additional energy is needed for more penetration, the Thin option may be necessary.

Wide: When even more energy is needed for more penetration, the Wide option may be necessary. High frequency applications, where resolution is a requirement, may require the Spike or Thin settings to achieve optimal results. Low frequency applications, where more penetration is a requirement, may require the Thin or Wide settings, offering increased penetration. The variety of transducer frequencies and diameters used in conjunction with the pulse width setting, enable you to fine tune the gauge to your application needs.

To adjust the Pulse setting:

Select MENU/PROBE/PULSE.


12 FLAW MODE (CG70ABDL only)

12.1 INTRODUCTION

Your gauge includes a basic flaw probe up mode. Further information on flaw detection can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

12.2 FLAW MODE VIEW

| Feature | Description |
|---------|---|
| A | Horizontal gridlines on the display represent increments of 25% of the full screen height |
| B | The thickness reading normally occupying this space is not relevant to flaw detection. It is replaced by a dashed line |
| C | The peak hold symbol is only visible when flaw mode is set to peak. Indicates the highest amplitude reflection detected during a scan. Pressing CLR will reset the position of the peak hold symbol to zero |
| D | Vertical gridlines on the labelled with quadrant numbers. Unlike thickness mode they do not correspond to the material thickness |



12.3 ENABLING FLAW MODE

To use Flaw Mode, an angle beam transducer and dual lemo to single microdot cable are required. These are available from Elcometer NDT.

1. Attach the dual lemo to microdot cable and angle beam transducer to the gauge.
2. Select MENU/PROBE/FLAW MODE.
3. Use the LEFT and RIGHT arrows to adjust the value of the FLAW MODE function (OFF, ON, PEAK):
 - OFF - Disables Flaw Mode
 - ON - Enables Flaw Mode

- PEAK - Enables the Flaw Mode and Peak Hold options and view. When this option is enabled, the peak hold symbol is displayed on the right side of the display (to reset to zero, press CLR).

4. Press MEAS to return to the measurement screen.

Note: When flaw mode is activated, a transducer delay will still be configured from the previously loaded transducer. This will only affect the position of the starting point from the initial pulse. The zero delay can be set to zero by loading the default setup located in the setup menu. Alternatively, you can load a factory flaw mode setup, and begin making any adjustments necessary.

13 MEASUREMENT - RECORDING YOUR READINGS

Your gauge is equipped with a data logger. With a data file open, all your measurements are saved into the file for later review and download to PC.

13.1 ABOUT THE DATA LOGGER

With a data file open, as you take measurements, the measurement data is stored in files in the gauge memory in Grid format similar to a spreadsheet format in which each cell is used to store a reading. Cells are referenced by the row number (1 to 999) and the column label (A to ZZ).

Data logger filename character sets

Any combination of the following characters can be used for file names:

- Numeric characters: 0 - 9
- Alpha Characters: A - Z
- Special Characters: ! ' _ # space / . - ()

What measurement data is saved

When a measurement is taken (irrespective of log file format), the following information is saved:

- The reading value.
- A screenshot, the nature of which will depend on what view the gauge was in at the time the reading was taken. For example, if the view was in B-SCAN, then a B-SCAN screenshot will be saved with the reading. This 'Save Graphics' option can be toggled on/off.

Memory capacity

You can create and save as many data files as required up to the maximum capacity of the gauge memory (32 Mbit). If you try to create a new file which exceeds the memory capacity, the gauge will display an error message. Saved data must be deleted in order to make the space available.

| Save Graphics Option | Memory Capacity (readings) |
|----------------------|----------------------------|
| On | 12 000 + |
| Off | 210 000 + |

13.2 CREATING A NEW DATA LOGGER FILE - GRID FORMAT

To create a GRID log data file:

1. Select MENU/DATA/NEW and press ENTER to continue.
2. Fill in a name and a note (if desired) for your data logger file.
3. Select the size of the grid. Grid positions are denoted by a number and a letter, where the letter is the column and the number is the row.

Use TOP LEFT and LOWER RIGHT to define the size of the grid. For example, a with the TOP LEFT set to A001 and LOWER RIGHT C003 would produce a 3x3 grid.

The grid can have a maximum of 52 columns and 999 rows.

4. Set the Auto Increment direction. This option allows you to select which direction the cursor moves after a reading is stored in terms of compass points. For example NORTH would move the cursor up a row, and WEST would move a column left.
5. Choose whether to activate SAVE GRAPHICS or not (snapshot of the A OR B scan on screen).
6. Finally create the log by scrolling to CREATE LOG, pressing ENTER and then OK to confirm. The measurement grid is now displayed along with the grid name on screen.

13.3 HANDLING LOGGER FILES

Once created, logger files may be opened or closed using the functions "OPEN" and "CLOSE" Closing logger files places the gauge in immediate mode and will prevent accidental saving of data into an inappropriate log.

13.4 STORING READINGS IN A DATA LOGGER FILE

1. Create a new data logger file or open an existing file.
The grid is displayed in the lower half of the measurement screen.
Note: Once the file is open, it will remain open until it is closed or another file is opened. If the gauge is switched off, the file will be opened automatically when the gauge is switched on again. Press the ENTER key to display the file from the measurement screen.
2. If you want to save the reading to a particular cell location, scroll to the desired cell.
Note: The cell location must be empty. If it already contains a reading and you want to save a new reading to the same location, refer to the instructions given in "Viewing and Deleting readings" on page 18.
3. Take a reading and then press ENTER.
The reading value is saved in the file at the location selected and the cursor advances to the next cell according to the rules set for the data logger file:
 - If INCR. DIR is set to NORTH, EAST, SOUTH or WEST, the cursor will advance one cell in the chosen direction. When the cursor reaches the last cell in the row or column it will return to the other end of the row or column.
Note: If you try to save a reading into a cell location which already contains a reading value, a warning message is displayed (see Deleting a reading).
4. To advance to a specific row number, press OK enter the row number. Press OK to advance directly to that row number in the grid log.
5. To toggle the display between DIGITS view and B-SCAN view, press ESC.
6. If you are unable to take a measurement due to the measurement location being physically inaccessible, press CLR.
The cell location in the data file is marked OBST (Obstruct).
7. The display of the log data file on the measurement screen can be switched on and off:
 - To switch off, press MEAS
 - To switch on, press ENTER.

13.5 VIEWING AND DELETING READINGS

With a data file open:

1. Use the arrows to scroll through the cells in the data file.
As the cursor is moved to a different cell, the display is updated with the display view saved with the reading (if SAVE GRAPHICS was set to YES). Readings stored in memory are indicated by MEM in the top left corner of the measurement screen (in place of the bars of the stability indicator).

- To delete a reading, scroll to the cell location, press CLR and then OK (or ESC to cancel).
The reading is deleted and if you wish you can now take another measurement and save the reading in this cell location.

13.6 EDITING A DATA LOGGER FILE

You can edit the following fields of data files:

- NAME, NOTE, and INCRement DIRection

To edit a file:

- Open the data file. (Select MENU/DATA/OPEN).
- Select MENU/DATA/EDIT and press ENTER.
The EDIT GRID screen is displayed and lists all the fields which can be edited.
- Scroll to the field you want to edit, press ENTER and then adjust the contents of the field using the techniques previously described to create a data file - see page 17.
- When finished, scroll to SAVE CHANGES, press ENTER and then OK (or ESC to cancel).

13.7 DELETING A DATA LOGGER FILE

- Select MENU/DATA/DELETE ONE GRID and press ENTER.
The DELETE GRID screen is displayed and lists all the data files stored in your gauge memory.
- Scroll through the list until the data file you want to delete is highlighted.
- Press OK (or ESC to cancel).

The file is deleted.

13.8 DELETING ALL DATA LOGGER FILES

Note: This will delete all the data logger files in gauge memory - use with caution.

- Select MENU/DATA/DELETE ALL GRIDS.
- Press ENTER and then OK to confirm (or ESC to cancel).

The data logger memory is erased - all files are deleted.

14 GAUGE SETUPS

Your gauge contains 64 configurable preset locations in which you can store custom gauge setups, each one optimised for a specific measuring application.

These gauge setups can save time when conducting routine inspections of the same job or project. This feature also helps to eliminate error between two or more users during the setup and calibration process.

The setups store:

- Measurement mode
- Transducer type
- Gain setting
- Scan mode setting
- Alarm settings
- Display type setting


As well as storing the setups in your gauge, you can also store the setups on a computer and transfer them bi-directionally using the PC interface software included with the gauge.

The factory supplied setups stored in the gauge cover some of the more typical applications commonly used with this type of instrument and may be modified freely by the user.

The PC interface software includes a default setup file that can be uploaded to the gauge at any time to restore factory settings. However, you should consider saving modified setups to an empty location rather than overwriting the factory setups in your gauge.

14.1 OPENING A SETUP

1. Select MENU/SETUP/OPEN and press ENTER to display the SETUP LIST BOX.
2. Scroll through the list of setups until the required setup is highlighted.
3. Press ENTER to activate the confirmation screen.
4. Press OK to load the setup from memory.
5. Press MEAS to return to the measurement screen.



14.2 SAVING AND EDITING A SETUP

Once the parameters and features have been adjusted for an application, you can save these setting to a specific setup location for future use.

It is sometimes necessary to rename a previously saved setup, or add additional comments about a particular setup. The other comments about the project may also be required for additional documentation purposes.

The following procedures outline the necessary steps for saving and editing a setup:

1. Select MENU/SETUP/SAVE and press ENTER to display the SAVE SETUP EDIT BOX.
2. Scroll to NAME and then press ENTER to edit its value:
 - When you have finished, press OK to enter the value.
3. If you want to add a note, repeat step 2 for NOTE.
4. When you have finished, scroll to SAVE SETUP and press ENTER. The setup list screen is displayed.
5. Scroll through the list of setups until the required location to save the setup is highlighted.
6. Press OK to activate the confirmation screen.
7. Press OK to save the SETUP, or ESC to cancel.

Note: The Name and Note parameters of a Setup can be edited at any time by repeating the Save Setup routine described above. Therefore, the Save Setup function can also be considered an Edit Function.



14.3 USING THE DEFAULT SETUP

Your gauge includes a default setup which you can use (as a last resort) if there are no other setups stored in the gauge. This gives you the ability to load and modify a basic setup as follows:

1. Select MENU/SETUP/DEFAULT SETUP and press ENTER to activate the confirmation screen.
2. Press OK to confirm.
3. Press OK again to confirm.

15 DATA TRANSFER SOFTWARE

Software is available which allows data to be transferred from your gauge to a PC. Presently Elcometer supplies ElcoMaster™ software for this purpose.

To set-up other types of communications software:

1. Start the communications software.
2. Configure the software using the following parameters:
Data Bits - 8, Parity - None, Stop Bits - 1, Baud Rate 1200 (to print a report), or 9600 to transfer data file.

Note: A report can be printed to a communications program (i.e. HyperTerminal), or printed to a serial printer using A4 or 8.5" x 11" paper.

3. Set the communications software COM port to the port number that the gauge is connected to.

15.1 TRANSFERRING MEASUREMENT DATA TO YOUR COMPUTER

15.1.1 RS-232 Connector

The RS-232 connector, located on the bottom end cap of the gauge, is a 2 pin female Lemo connector. It is designed to connect directly from the gauge to a standard AT serial port on a PC. A Lemo to 9 pin serial cable is supplied with the gauge.

Note: This connector is also used to upgrade the gauge with the latest version of firmware.

15.1.2 USB to Serial Converter

Some newer laptop computers do not have standard serial ports. In this case, use the USB to Serial converter supplied with the gauge.

15.1.3 Computer System Requirements

ElcoMaster™ is compatible with any Windows computer system running Windows XP or above.

15.1.4 Using the XFER menu

The XFER menu of your gauge is used in conjunction with the ElcoMaster™ PC software. The steps below outline the procedure for accessing the XFER menu and basic operation as follows:

1. Scroll to the XFER section of the main menu.
2. Press the ENTER key to activate the option selected.
3. Once the Backup or Restore function has been completed, press the MEAS key once to return to the menu items, or twice to return to the measurement mode.

16 STORAGE



Your gauge has a Liquid Crystal Display. If the display is heated above 50°C (120°F) it may be damaged. This can happen if the gauge is left in a car parked in strong sunlight. Always store the gauge in its case when it is not being used.

If the gauge is to remain unused for long periods of time, remove the batteries and store them separately. This will prevent damage to the gauge in the event of malfunction of the batteries.

17 MAINTENANCE

You own one of the finest corrosion gauges in the world. If looked after, it will last a lifetime.

17.1 FAULTS

Your gauge is designed to give many years reliable service under normal operating and storage conditions. The gauge does not contain any user-serviceable components. In the unlikely event of a fault, the gauge should be returned to your local Elcometer NDT supplier or directly to Elcometer NDT. The warranty will be invalidated if the instrument has been opened.

17.2 TRANSDUCER

The transducer will wear with repeated use. To extend transducer life, always set the transducer down so that it is perpendicular to the panel surface. Dragging the transducer along the surface will reduce the life of the transducer. Replacement transducers are available from your local Elcometer NDT supplier or directly from Elcometer NDT.

18 TECHNICAL SPECIFICATION

| | | |
|---|----------------|---|
| Measurement Rate | Manual | 4 readings per second |
| | Scan mode | 32 readings per second |
| Measuring Range ^a - Sound Velocity | | 1250 m/s to 10000 m/s (0.0492 in/μs to 0.3930 in/μs) |
| Measuring Range - Thickness | Pulse-Echo P-E | 0.63 mm to 254 mm (0.025" to 9.999") |
| | Echo-Echo E-E | 2.54 mm to 102 mm (0.1" to 4.0") Range will vary +/- depending on the coating. |
| Measurement Resolution | Sound Velocity | 1 m/s (0.0001 in/μs) |
| | Thickness | 0.01 mm (0.001") |
| Velocity Calibration Range | | 1250 m/s to 10000 m/s (0.0492 in/μs to 0.3937 in/μs) |
| Weight (including batteries) | | 380 g (13.5 oz) |
| Dimensions (W x H x D) | | 63.5 mm x 165 mm x 31.5 mm (2.5" x 6.5" x 1.24") |
| Gauge Operating Temperature | | -10°C to 60°C (14°F to 140°F) |
| Case | | Aluminium case with gasket sealed end caps and waterproof membrane keypad |
| PC Connection | | RS232 serial port. Windows PC interface software |
| Display | | Backlit VGA greyscale display (240 x 160 pixels). Viewable area 62 mm x 45.7 mm (2.4" x 1.8"). EL backlit (on/off/auto). |
| Power Source | | Three 1.5V AA alkaline or 1.2V rechargeable cells. Typically operates for 200 hours on alkaline and 120 hours on rechargeable cells (charger not included.) <i>Note: Alkaline batteries must be disposed of carefully to avoid environmental contamination. Please consult your local environmental authority for information on disposal in your region. Do not dispose of any batteries in fire.</i> |

a. Measuring Range depends on material, surface conditions and the transducer selected.

19 WARRANTY

Elcometer NDT warrants your gauge against defects in materials and workmanship for a period of two years from receipt by the end user.

Additionally, Elcometer NDT warrants transducers and accessories against such defects for a period of 90 days from receipt by the end user. If Elcometer NDT receives notice of such defects during the warranty period, Elcometer NDT will either, at its option, repair or replace products that prove to be defective. The warranty will be invalidated if the instrument has been opened.

19.1 EXCLUSIONS

The above warranty shall not apply to defects resulting from: improper or inadequate maintenance by the customer; unauthorised modification or misuse; or operation outside the environmental specifications for the product.

Elcometer NDT makes no other warranty, either express or implied, with respect to this product. Elcometer NDT specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Some states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion may not apply to you. However, any implied warranty of merchantability or fitness is limited to the two-year duration of this written warranty.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from country to country, state to state or province to province.

19.2 OBTAINING SERVICE DURING WARRANTY PERIOD

If your hardware should fail during the warranty period, contact Elcometer NDT and arrange for servicing of the product. Retain proof of purchase in order to obtain warranty service.

For products that require servicing, Elcometer NDT may use one of the following methods:

- Repair the product
- Replace the product with a re-manufactured unit
- Replace the product with a product of equal or greater performance
- Refund the purchase price.

19.3 AFTER THE WARRANTY PERIOD

If your hardware should fail after the warranty period, contact Elcometer NDT for details of the services available, and to arrange for non-warranty service.

20 SPARES & ACCESSORIES

20.1 TRANSDUCERS

Elcometer NDT gauges are **not** supplied with a transducer as standard - this must be ordered separately.

The transducers listed below are the most commonly used however, Elcometer NDT offer a wide range of other transducers to suit various applications.

Further information on the transducers available and their applications can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

| Description | Sales Part No. |
|---|-----------------------|
| 2.25 MHz 1/4" Potted Side Transducer | TX2M25CP-2 |
| 5 MHz 1/4" Potted Side Transducer | TX5M00CP-4 |
| 5 MHz 1/4" Potted Side High Damped Transducer | TX5M00CP-10 |
| 7 MHz 1/4" Potted Side High Damped Transducer | TX7M50CP-6 |
| 10 MHz 1/4" Potted Side Transducer | TX10M0CP-4 |
| Dual Lemo to Single Microdot Transducer Cable | TL-24030-8 |
| 2.25 MHz 1/4" Microdot Side Mini Angle Beam Transducer, 45 Degree | TF2M25C45M |
| 5 MHz 3/8" Microdot Side Mini Angle Beam Transducer, 60 Degree | TF5M00D60M |
| 10 MHz 3/16" Microdot Side Mini Angle Beam Transducer, 70 Degree | TF10M0B70M-1 |

20.2 CALIBRATION BLOCKS

Elcometer NDT offer a comprehensive range of calibration blocks to suit a wide range of applications and standards.

Selecting the correct calibration block for the application is essential to ensure accurate evaluation. The form, shape and material of the calibration block should be appropriate for the material being inspected. Any artificially induced flaw should closely resemble that of the actual flaw being tested for.

The calibration blocks listed below are a selection of those available - details of the full range can be found on www.elcometerNDT.com

| Description | Sales Part No. |
|---|-----------------------|
| Calibration Block: 8 Step; 1 - 8mm | TW-24005-* |
| Calibration Block: 10 Step; 2 - 20mm | TW-24006-* |
| Calibration Block: 10 Step; 2.5 - 25mm | TW-24007-* |
| Replace * with S1018 = 1018 Steel Block; A = Aluminium Block; SS = Stainless Steel Block; T = Titanium Block. | |

20.3 ULTRASONIC COUPLANT

Each gauge is supplied with a 120ml (4 fl oz) bottle of standard ultrasonic couplant. Replacement bottles and couplant for high temperature applications are available from your local Elcometer NDT supplier or directly from Elcometer NDT.

| Description | Sales Part No. |
|--|-----------------------|
| Ultrasonic Couplant, 120 ml (4 fl oz) | TC-24034-1 |
| Ultrasonic Couplant, 360 ml (12 fl oz) | TC-24034-2 |
| Ultrasonic Couplant, High Temperature 510°C (950°F), 60 ml (2 fl oz) | TC-24034-9 |

Note: A wide range of other transducers and accessories is available - see www.elcometerNDT.com for details.

20.4 MISCELLANEOUS

| Description | Sales Part No. |
|-------------------------------------|-----------------------|
| RS232 Cable USB to Serial Converter | TL-24031 |

21 CONDITION AND PREPARATION OF SURFACES

Further information can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

22 APPLICATION NOTES

Further information can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

23 SOUND VELOCITIES OF COMMON MATERIALS

| Material | Sound velocity | |
|---------------|----------------|--------------------|
| | (m/s) | (in/μs) |
| Aluminium | 6350 | 0.250 |
| Bismuth | 2184 | 0.086 |
| Brass | 4394 | 0.173 |
| Cadmium | 2769 | 0.109 |
| Cast Iron | 4572 | 0.180 (Approx.) |
| Constantan | 5232 | 0.206 |
| Copper | 4674 | 0.184 |
| Epoxy Resin | 2540 | 0.100 (Approx.) |
| German Silver | 4750 | 0.187 |
| Glass, Crown | 5664 | 0.223 |
| Glass, Flint | 4267 | 0.168 |
| Gold | 3251 | 0.128 |
| Ice | 3988 | 0.157 |
| Iron | 5893 | 0.232 |
| Lead | 2159 | 0.085 |
| Magnesium | 5791 | 0.228 |
| Mercury | 1448 | 0.057 |
| Nickel | 5639 | 0.222 |
| Nylon | 2591 | 0.102 (Approx.) |

| Material | Sound velocity | |
|--------------------|----------------|--------------------|
| | (m/s) | (in/μs) |
| Paraffin | 2210 | 0.087 |
| Platinum | 3962 | 0.156 |
| Plexiglas | 2692 | 0.106 |
| Polystyrene | 2337 | 0.092 |
| Porcelain | 5842 | 0.230 (Approx.) |
| PVC | 2388 | 0.094 |
| Quartz Glass | 5639 | 0.222 |
| Rubber, Vulcanised | 2311 | 0.091 |
| Silver | 3607 | 0.142 |
| Steel | 5918 | 0.233 |
| Steel, Stainless | 5664 | 0.223 |
| Stellite | 6985 | 0.275 (Approx.) |
| Teflon | 1422 | 0.056 |
| Tin | 3327 | 0.131 |
| Titanium | 6096 | 0.240 |
| Tungsten | 5334 | 0.210 |
| Water | 1473 | 0.058 |
| Zinc | 4216 | 0.166 |
| | | |

24 THE MENU COMMANDS

Note : Certain menu commands are not accessible on some CG70 models

| Menu | Function | Description |
|------------------------|--------------------|--|
| PRB (PROBE) | ZERO TRANSDUCER | Zeros your gauge in much the same way that a mechanical micrometer is zeroed. If your gauge is not zeroed correctly, all of the measurements made may be in error by some fixed value. |
| | TYPE | Use this function to select the type of transducer being used from a chart of transducer types. This provides increased linearity between transducers. |
| | FLAW MODE | Activates the flaw detection mode and view. This feature is for use with single element angle beam transducers and used as a general prove-up flaw inspection mode. |
| | PULSE | Your gauge has adjustable pulse width for both high penetration and resolution applications. The pulse width refers to the duration of time the pulser is on. The options are SPIKE, THIN, and WIDE. |

| Menu | Function | Description |
|------------------------------|-----------------|---|
| CAL (CALIBRATION) | MATERIAL | Select the material velocity from a chart of basic material types when a known sample thickness, or material velocity cannot be obtained. |
| | ONE-POINT | Performs a single point calibration. This function allows you to automatically calculate the velocity by entering a known sample thickness. |
| | TWO-POINT | Performs a two-point calibration. This function allows you to automatically calculate the velocity by entering a second known sample thickness. |
| | UNITS | Toggle between Metric (millimetres) or English (inches) units. |
| | VELOCITY | This function calibrates your gauge by setting the velocity to a known material velocity. |
| DISP (DISPLAY) | VIEW | Choose between RF wave, RECT (rectified) wave, BSCAN (cross section), and DIGITS (large digits) views. |
| | DELAY (B-START) | Adjust where the left side of the display window starts according to thickness, in inches or millimetres. |
| | RANGE (B-DEPTH) | Set the overall depth of the viewable measurement area. It functions a lot like a zoom on a camera. |
| | CONTRAST | Adjusts the contrast of the display. |
| | BACKLIGHT | Select backlight option of OFF, ON or AUTO. In AUTO mode the backlight is only switched on when the gauge is making a measurement. |
| TUNE | POLARITY | The gauge operates on a zero crossing detection principle. This feature toggles which stroke of the cycle the crossing detection uses, either positive or negative. |
| | GAIN | Increases or decreases the overall amplitude of the signal. Gain is similar to the volume control on a stereo receiver. |
| | AGC | When operating in E-E mode, the gauge adjusts the gain automatically. Alternatively, the AGC can be manually controlled. |
| GATE | GATE 1 | Sets the start of the gate, according to time/distance. |
| | GATE 2 | Set the start position of gate 2 (E-E mode only). |
| | MEASURE MODE | Select the measurement mode. |
| SET UP | OPEN | Displays a list of factory and user-defined setups currently stored in memory. These setups can be recalled and used at any time. |
| | SAVE | Save a custom setup that you have modified or created. |
| | DEFAULT SETUP | Loads a basic default setup. Use only as a last resort if the setups in your gauge have been corrupted and a computer is not accessible. |
| | LANGUAGE | Select the menu language. |

| Menu | Function | Description |
|-------------------------|-----------------|---|
| DATA | NEW | Creates a new alpha numeric grid. You can customise the grid file according to your requirements. |
| | EDIT | Modify the parameters of grid files previously saved. <i>Note: Predefined coordinates cannot be changed once they have been created.</i> |
| | OPEN | Recalls existing grids files from gauge memory. |
| | DELETE ONE GRID | Deletes a selected grid file from memory. |
| | DELETE ALL GRID | Deletes all files currently stored in memory. |
| UTIL (UTILITIES) | AUTO FIND | Automatically locates the detection point if the measurement is out of the viewable display area. |
| | SCAN MODE | Enables a high speed scan mode that increases the overall sample rate from 24 to 50 measurements per second, depending on the current measurement mode used. |
| | ALARM STATUS | Toggles alarm mode ON, OFF, or AUDIBLE. |
| | ALARM HIGH | Sets the HI limit parameter. If the measurement exceeds this value, a red light will illuminate and the alarm will sound. |
| | ALARM LOW | Sets the LOW limit parameter. If the measurement falls below this value, a red light will illuminate and the alarm will sound. |
| XFER (TRANSFER) | BACKUP SETUPS | Allows you to backup the setups currently stored in your gauge to a computer via the RS232 port. |
| | RESTORE SETUPS | Allows you to restore setups saved on a computer to your gauge via the RS232 port. |
| | BACKUP GRID | Allows you to backup grids files stored in your gauge to a computer via the RS232 port. |
| | RESTORE GRID | Allows you to restore grids files saved on a computer to your gauge via the RS232 port. |
| | ABOUT | Provides Elcometer NDT contact information and your gauge software version. Refer to the help section of your gauge ElcoMaster™ for a complete electronic manual covering data transfer. |